


REV. #	DATE	NOTES
01	2015-03-02	CHANGE MATERIAL THICKNESS TO 0.030"
01	2015-03-02	REMOVE WRONG PART # FROM TITLE BLOCK SHEET 2



MATERIAL	POLYCARBONATE OR PET-G 0.030"
FINISH	

CLEARNAV INSTRUMENTS	
CN PART #	
REVISION #01	DATE: 2015-03-02
UNITS:	TOL +/-:
MODEL NAME: TEMPLATE_TUNNEL_NEW	
DWG NAME: TEMPLATE_TUNNEL_NEW	
SHEET 1	OF 2

REV. #	DATE	NOTES

Directions

NOTE: Dimensions are for reference only and are not needed if you are using the template supplied. A DXF file is also available on our website.

Recommended cutout dimensions are shown on Sheet three if you do not wish to use the template.

1. Cover the area of the panel where the instrument is to be mounted with masking tape
2. Locate template on panel then tape it in place
3. Use a 1/16" [1.5mm] drill and make six pilot holes
4. Use a #16 [4.5mm] drill and enlarge the four mounting hole pilot holes
5. Use a 5/16 [8.0mm] drill and enlarge the two bottom corner holes of the cutout area
6. Use a sharp pencil or a fine point pen and mark the cutout area
7. Remove the template and cut the opening for the instrument using the cutting tool of your choice

